

QUICK INSTALLATION SETUP

Step 1. Connect the Ethernet cable from your router's Ethernet (LAN) port into the INTERNET port of the UNOVON Phone Adapter.

Step 2. Connect a standard analog telephone to the PHONE port of the UNOVON Adapter using a standard phone cord. For cordless phone systems make sure telephone cord is connected to the base transmitter.

Step 3. Connect the provided power supply to the POWER port of the UNOVON Adapter. Connect the other end into the power source.

Step 4. Wait for a minute. Verify that the Power, Internet, Phone light indicators on the front of the UNOVON Adapter are steady. Pick up the phone receiver and you should hear dial tone. Now you are ready to place calls.

